

**INSTALLATION INSTRUCTIONS**  
**FRONT RUNNER**  
**2014 TOYOTA HIGHLANDER**  
**PART # FRTO-732-25-03S**

**PARTS LIST:**

1	Driver/Left Mounting Bracket	2	Lock Washers
1	Passenger/Right Mounting Bracket	8	Nuts
1	Front Runner	16	Flat Washers
10	Bolts		



Cuts must be made to the plastic skid shield to allow clearance for the brackets



After cutting plastic, install bracket onto vehicle using drop in bolts.

Attach bar to brackets and tighten all bolts

**Fig 1**

