



Fits: 2011-2019 Toyota Sienna R Series Running Boards



ALL TOOLS AND HARDWARE INCLUDED IN BOX



REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT.



READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.



DO NOT OVER TORQUE. STANDARD OPERATING LOAD FOR TIGHTEN BODY MOUNT NUTS & BOLTS VARIES FROM **45** TO **65** FOOT POUND.

SCAN
OUR
READER
FOR
MANUAL



4HR



Cutting is
Required



Drilling is
Required



INFO@BROADFEET.COM




TEL: 718-302-1787

STEP 1:

Open up the box of brackets and hardware to make sure you have all the items listed below before you initiate the installation.



BOLT PATTERN FOR SUCCESSFUL INSTALLATION





Fits: 2011-2019 Toyota Sienna R Series Running Boards



STEP 2:

There are two models of Sienna. There are models with SPARE TIRES or models that DON'T HAVE THEM. This instruction is for models that have NO SPARE TIRE. If you do have the spare tire please read the other booklet. Picture on the left shows you the brackets that you'll be using.



STEP 3:

Start by removing the splash guards under the car where the holes needed to install the brackets are situated.



STEP 4:

Driver side front is required drilling to insert the Molly Rivet nut. You have to make sure the holes are wide enough for a perfect fit.





Fits: 2011-2019 Toyota Sienna R Series Running Boards



NOTE 4:

Now that you have drilled the driver side front hole, you should be able to insert the T-bolt or Droppin with no issue. Add the plastic retainer to secure the bolt. This will keep it firm for the next step.

NOTE 5:

Once you install the driver side bracket following all the steps accordingly. Your bracket should look just like the photo below.



NOTE 6:

The picture to the left shows the Driver side rear.





Fits: 2011-2019 Toyota Sienna R Series Running Boards



NOTE 7:

Middle driver & Passenger side require drilling and insert Two molly Rivet nut.





Fits: 2011-2019 Toyota Sienna R Series Running Boards



NOTE 8:
Driver Side Front Bracket kit with Support L bracket

NOTE 9:
Rear Passenger side with Spare Tire(doesn't require support bracket)
Rear Passenger side without Spare tire will be able to use support bracket

NOTE 10:
Front Passenger side with U-Bolt





Fits: 2011-2019 Toyota Sienna R Series Running Boards

NOTE 11:

Hold plastic cover up in position to determine area to cut from cover. Inside of driver side cover. Cut cover only enough to clear Brackets. Please make sure to cut as it is shown in the images below.



**PLEASE TIGHTEN ALL BOLTS
TO THE BEST OF YOUR ABILITY**

**YOUR RUNNING BOARDS HAS BEEN SUCCESSFULLY
INSTALLED**



**PLEASE RE-INSTALL YOUR SPLASH GUARD AND MODIFY
WHAT YOU NEED TO MAKE SURE YOUR BRACKETS FIT
PROPERLY THROUGH THE SPLASH GUARD.**





Fits: 2011-2019 Toyota Sienna R Series Running Boards

**PLACE THE
RUNNING
BOARDS ON
TOP OF THE
BRACKETS
AND MOUNT
AS SHOWN**



BRACKET



**PLEASE SCREW BRACKETS WITH BOLTS AS
SHOWN IN THE DIAGRAM TO THE LEFT**



**R66 INSTALLS
ONLY**

**FOR R66 LIGHTED RUNNING BOARD
STEP 1: PLEASE FIND THE DOME LIGHT
WIRE IN YOUR VEHICLE DOOR PANEL**

**STEP 2: CONNECT POWER AND GROUND
SUCCESSFULLY AND TEST
TO MAKE SURE LIGHTS TURN ON
PROPERLY**

